Product Description: ZX122S1APS is PCISIG M.2 breakout adapter providing access to all PCISIG signals as well as providing method of power supplies test and measurement. ZX122S1APS is breakout adapter to be used for:

- 1- Test and measurement for signal quality, characterization, test and debug of any PCISIG signals via onboard 0405 SMD shunt landing pads.
 - a) Each PCISIG (excluding GND signals) are routed to 0402 SMD shunt package for easy probe access.
 - b) Each 0402 SMD shunt package may be wired for signal measurement via scope / test equipment.
 - c) Each 0402 SMD shunt package may be cut and redirected to another signal (onboard or offboard) for test and debug.
- 2- Measure and analyze power supply ripple, transients, Device Under Test, DUT, power consumption and more.
 - a) Each power supply rail is designed with current sensing power resistor, please see block diagram.
 - b) Utilizing scope probe test equipment, measure power supply noise, ripples, transients, and DUT power consumption.
 - c) Utilizing eLoad (Electronic Load), qualify host's power supply & maximum output power.
 - d) Identify power supply trace impedance, Rdc , for improved Host / DUT PCB design.

ZX122S1APS features:

Ε

- 1- Provides access to ALL PCISIG signals via onboard 0402 SMD shunt packages
- 2- Onboard current sense resistors for all supply rails Please see table 1 for details.
- 3- Listed number adjacent to each 0402 SMD shunt package represents the associated PCISIG M.2 connector's pin number.
- 4- All traces are 50 Ohms impedance controlled.
- 5- Four layers PCB design, inner layers are GND planes.
- 6- Accessible GND exposed copper, enabling for ease of access for test and measurement.
- 7- Mates with any key matching M.2 Host and Device / DUT
- 8- The module is shipped with 12pc of probing wires, ZX00BC2PH30, See ordering information

Electrical: Insertion loss > -2dB @6GHz Trace impedance: 50Ω

> Operating Temperature: -65 °C to +170 °C M.2 Edge Connector type (J1): Key A

Mates with: M.2 Key A Plating: Gold 100U M.2 Receptacle (J2):

Key Type: Key A Height: 0.16" (4.2mm)

Spacer: 0.1" (2.54mm) - See Figure 3

Plating: Gold 100U

Current per pin: 0.5A (maximum)

Current Sense:

R1, R2: 10mΩ 2512 SMD 7W - Thickness: 0.02" (0.5mm) Max - See Figure 3

Ratings: AEC-Q200

Temperature Coefficient: ±75ppm / °C

Operating Temperature:-65 °C to +85 °C at 100% listed power rating, see Table 1 -65°C to +170°C see section Power Rating on page 3

Shunt:

Package: 0402 SMD

Current Sense resistors: Table 1 lists onboard ZX122S1APS current sense resistors and associated PCISIG M.2 connector assignment

Table 1						
	Current Sense Resistor	PCISIG M.2 Connector pin	PCISIG M.2 Supply Rail	Description	Package	
		number			(inch)	(mm)
	R1	2, 4	3.3 V	10m Ohms 1% 7W	2512	6432
	R2	72, 74	3.3 V	10m Ohms 1% 7W	2512	6432

Compliance: ISO2001 certified

0.02" (0.5mm)

Bare solid copper to pin header wire embly . ZX00BC2PH30 Zebax.com

Figure 3- M.2 receptacle

RoHs - Lead Free EU RoHS2 UL E111594 document ELV- Vehicle Directive (Directive 2000/EC) European Union Directive (203/11/EC) Halogen Free per IEC-61249-2.21: 2003 RoHs Directive 2011/65/EU

Certificate of Compliance for Radioactive substances

Certificate of Compliance for Asbestos

WEEE Directive (2012/12/EU)

Certificate of Compliance for Ozone Depleting Substances, ODS

Certificate REACH SVHC

Certificate of Compliance RoHS EN CoC

Part number ZX122S1APS

Figure 2 - Circuit diagram

Shunt 0402 SMD package 0 Ω

 $50~\Omega~$: All traces are designed $50~\Omega$ trace impedance control

1.029" (26mm) ZEBAX.com ZX122S1APS (30mm)

Figure 1 - ZX122S1APS Block diagram



-0.78" (19.85mm)

in thumbundaning in

ZX122S1APS

Zebax.com

R1, R2: current sense 3.3V / VBAT resistor 51 .. 54 PCISIGN connector pin number routed to the 0402 SMD shunts

ZX122S1APS package includes:

PCB Edge Quantity Description M.2 PCISIG Socket 1 Key A module Key A Key A ZX00BC2PH30 32AWG Bare Copper wire to pin header wire assembly

ZX00BC2PH30 site page for ordering ZX00BC2PH30 wire assembly

ZEBAX TECHNOLOGIES

SANTA CRUZ, CA U.S.A (831) 2 2 2 - 0717 WWW.ZEBAX.COM

SPECIFIED DIMENSIONS ARE INCHES (MM). ROHS COMPLIANT

ASSEMBLY DRAWING ITEM: ZX122S1APS

DESCRIPTION:

PCISIG M.2 NGFF Socket 1 Key A passive breakout adapter power measurement module

CHECKED: M. MARINA

REVISSION: 1.0 MATTHEW CT

ALL ZEBAX TECHNOLOGIES DESIGN SPECIFICATIONS, DRAWINGS, PUBLICATIONS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." ZEBAX MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NO INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. Information furnished is believed to be accurate and reliable. However, Zebax Technologies assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. Specifications mentioned in this publication are subject to change without notice. This publication replaces all other information previously supplied. Zebax Technologies products are not authorized as in life support devices or system

SHEET: 1 OF 3

ZX122S1APS Product Name: ZX122S1APS PCISIG M.2 NGFF Socket 1 Key A passive breakout adapter - power measurement module - Page 2 of 3 **Current Sense resistors:** The current sense resistors may be removed if external electronic load, eLoad, is used. eLoad test equipment may be applied to ZX122S1APS for power supply Figure 4 – Typical application - Rx, Ry : Current sense resistors characterization, test and measurements. Eload suppliers: BK Precision, Chroma, Instek, Kikusui and more Table 2 – PCISIG M.2 Socket 1 Key A Table 2 represents only the PCISIG M.2 Socket 1 Key A power supply and the assigned GND, **Signal assignments:** Table 2 exhibits the routed M.2 PCISIG signals on the ZX122S1APS module. PCISIG M.2 reference ground, signal assignments for "Socket 1 Key A" applications. Socket 1 DisplayPort Key A 1- Table 2 represents only the PCISIG M.2 Socket 1 Key A power supply and the assigned GND, PCISIG M.2 connector pin PCISIG M.2 reference ground, signal assignments for "Socket 1 Key A" applications. ZX122S1APS Signal Signal Label¹ Label¹ 2- Table 2 represents only the PCISIG M.2 Socket 1 Key A signal assignments for the listed application. 3.3 V GND Ε However; there are other PCISIG signal assignment for the M.2 Socket 1 Key A design configuration. All $R2^2$ 3.3 V 72 73 73 REFCLKn1 PCISIG M.2 assigned Power Supply rails and GND reference M.2 pin assignments are identical across PEWAKE1# (I/O)(0/3.3V) 70 70 71 71 REFCLKp1 PCISIG M.2 Socket 1 Key A solutions. Please apply your design signal name convention to non-power CLKREQ1# (I/O)(0/3.3V) 68 68 69 GND supply rail signals as the listed signal names on the Table 1 applies to the listed specific M.2 application. PERST1# (I)(0/3.3V) 66 66 67 PETn1 RESERVED 64 64 65 65 PETp1 ALERT# (O)(0/1.8V) 62 62 63 GND **Ground / Exposed Copper:** I2C CLK (I)(0/1.8V) 60 60 PERn1 61 All of the PCISIG M.2 GND, reference ground, signals are connected to each other along with the 2 inner I2C DATA (I/O)(0/1.8V) 58 58 59 59 PERp1 GND planes. In addition; the exposed copper on the ZX122S1APS is the module's GND for purpose of 56 57 GND W DISABLE1# (I)(0/3.3V) 56 rework and probing purpose. W DISABLE2# (I)(0/3.3V) 54 54 55 55 PEWAKE0# (I/O)(0/3.3V) PERST0# (I)(0/3.3V) 52 52 53 53 CLKREQ0# (I/O)(0/3.3V) 50 SUSCLK (I)(0/3.3V) 50 51 GND PCISIG M.2 signals: D COEX RXD (I)(0/1.8V) 48 48 49 REFCLKn0 ZX122S1APS passes through all PCISIG M.2 signals (excluding the power supply rails . All traces are 50 46 46 47 47 REFCLKp0 COEX TXD (O)(0/1.8V) Ohms impedance controlled. ZX122S1APS passes through the reserved "NC" No Connect signals as well. GND COFX3 (I/O)(0/1 8V) 44 44 45 VENDOR DEFINED 42 42 43 43 PETn0 VENDOR DEFINED 40 40 41 41 PETp0 VENDOR DEFINED 38 38 39 GND GND 36 37 37 PERn0 **Application:** Bringup, testing, emulation, development, modular design evaluations DP ML0p 34 34 35 35 PERp0 M.2 PCISIG Socket power supply test characterization DP ML0n 32 32 33 GND SDIO SSD SATA WWAN DP WIFI GPS GYRO Compass BT FM sensor module GND 30 31 DP_HPD (I/O)(0/3.3V) DP MI 1n 29 28 28 CND Socket 1 Add-in Card Key A-E, Socket 1 DisplayPort Key A, Socket 1 SDIO Key E DP ML2n DP MI 1n 26 26 27 Socket 2 WWAN Key C, Socket 2 PCle-based SSD Key B-M, Socket 2 SATA-based SSD Key B-M GND 24 25 25 DP ML2n Socket 2 PCIe / USB 3.1 Gen1-Based WWAN Key B, Socket2 PCIe-Based WWAN Key B DP AUXo 22 22 23 GND Socket 2 USB3.1 Gen1-based WWAN Key B, Socket 2 SSIC WWAN Key B DP AUXn 20 21 21 DP ML3p Socket 3 PCle-based Key M, Socket 3 SATA-based Key M GND 18 19 DL_ML3n DP MLDIR GND (I)/ 3.3V (O)/NC (I/O) LED 2# (O)(OD) 16 17 14 15 12 13 ADD-IN CARD KEY A ADD-IN CARD KEY A 10 11 Mates with: Any standard M.2 NGFF PCISIG connector on host and device Key A 8 TE 2199125 2199119 2199230 2199133 JAE SM3ZS067 LED_1# (O)(OD) 6 GND USB D-4 Bellwether: SD-80148 SD-80149 SD-80152 SD-80159 Amphenol $R1^2$ USB D+ Note 1: Label is the labled number on the adjacent 0402 SMD shunt package on the ZX122S1APS module. The listed signal name in table 2 may vary Module Insertion, Removal process: depending to your M.2 design configuration. Please apply your design signal name convention to non-power supply rail signals & GND.

In order to avoid any mechanical stress or damage to ZX122S1APS, please follow the below listed guidelines for insertion and removal process:

- 1- Move the Module against the housing chamber, see figure 1
- 2- Rotate module to 25°, insert it until the module surface reaches the ramp, figure 2, 3
- 3- Rotate the module to horizontal position, see figure 4
- 4- Fix the module by screw, see figure 5

2: The supply power is available on the listed current sense resistor.

ZEBAX TECHNOLOGIES SANTA CRUZ, CA U.S.A (831) 2 2 2 - 0717 WWW.ZEBAX.COM ASSEMBLY DRAWING SPECIFIED DIMENSIONS ARE INCHES (MM). ITEM: ZX122S1APS ROHS COMPLIANT PCISIG M.2 NGFF Socket 1 Key A passive DESCRIPTION: breakout adapter power measurement module

ALL ZEBAX TECHNOLOGIES DESIGN SPECIFICATIONS, DRAWINGS, PUBLICATIONS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." ZEBAX MAKES NO WARRANTIES. EXPRESSED. IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NO INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE

Information furnished is believed to be accurate and reliable. However, Zebax Technologies assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. Specifications mentioned in this publication are subject to change without notice. This publication replaces all other information previously supplied. Zebax Technologies products are not authorized as in life support devices or systems

CHECKED:

MATTHEW CT

REVISSION: 1.0 SHEET: 2 OF 3 Е

D

C

В

M. MARINA

Product Name: ZX122S1APS PCISIG M.2 NGFF Socket 1 Key A passive breakout adapter - power measurement module - Page 3 of 3

Ε

D

В

Typical Application: ZX122S1APS is designed for purpose of PCISIG M.2 power supply characterization, test and debug at full connector's bandwidth. It provides onboard current sense resistors where scope probe could be utilized for measuring characterization data for qualifying the host or device functional behavior. Additionally, the current sense resistors may be replaced by eLoad for transient and dynamic load throttling. Below are few suggestions in respect to proper power supply measurements using ZX122S1APS module:

Scope Probe wire Installation:

Utilize the supplied ZX00BC2PH30 bare copper to pin wire assembly whenever possible - Based on availability of type of scope + probing options, install probe wire as listed below

- 1- It is recommended to keep the +probe wire length at 0.5" (1.2cm) long.
- 2- In order to avoid ground loop problems, please use the shortest Ground probe wire interfacing to the nearest GND reference. ZX122S1APS provides several exposed copper test points for probing purpose.
- 3- Ensure scope probe's bandwidth is set at 20MHz Certain tests require full scope + scope probe bandwidth; however. industry standard is 20MHz bandwidth for power supply test and measurements.
- 3- Both Keysight as well as Tektronix offer variety of single ended as well as differential probes along with their accessories, below are few probes from each vendor:
 - a) Keysight differential probe or similar N2795A, N2796A, 1168V, 1134B along with E2677B differential Solder-in probe, N5426A ZIF Tip, N2884A Fine Wire ZIF Tip and more - See the figure "probe head accessories".
 - b) Tektronix offers several single-ended as well as differential probes such as: P6243, P6245, P6248, P6246, P6247 or any TP1500, TAP2500, TAP3500, TAP4000, P7240 of TDP7000 series or equivalent
- 4- Please follow your vendor's guideline in installation of probe wires & accessories.

Power Rating: Onboard current sense resistors on ZX122S1APS module are designed for maximum power consumption per PCISIG M.2 specification operating within -65 °C to 85 °C temperature range. The current sense resistor's power rating will degrade at above 85 °C test environment. It is highly recommended to utilize external cooling fan if your design expects to exceed maximum current via each PCISIG M.2 pin (0.5A per pin) at above 85 °C test environment.

> The onboard current sense resistors operate at 100% listed power ratings (see Table 1) within temperature range : R1, R2: -65° C \leq operating temperatures \leq 85 $^{\circ}$ C with tolerance = \pm 1%

The onboard current sense resistors **power ratings** derail at **above** 85 ℃. Figure 4 exhibits the current sense resistors derating curve. Current sense resistors rated power: $P = VI = I^{**}2 \times R$ where I is the maximum current for the listed resistor value R

Below are few suggestions, if your test & measurement environment falls ≥ +85 °C temperature range:

- 1- Apply cooling fan where the current sense resistor's terminal blocks are measured at 85 °C Please note The ZX122S1APS module design provides heatsink solution to the onboard current sense resistors via inner layers thermal distribution method.
- 2- Replace the onboard current sense resistors with lower values (similar footprint), resulting at higher power ratings at ≥ 85 °C test environment.
- 3- Replace onboard current sense resistors with eLoad (electronic Load Board / System) eLoad system resides outside of test chamber, therefore it is not subject to temperature degradation.






Figure 4 – Current sense resistor Derating chart



ALL ZEBAX TECHNOLOGIES DESIGN SPECIFICATIONS, DRAWINGS, PUBLICATIONS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." ZEBAX MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NO INFRINGEMENT. MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, Zebax Technologies assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. Specifications mentioned in this publication are subject to change without notice. This publication replaces all other information previously supplied. Zebax Technologies products are not authorized as in life support devices or system





ZEBAX TECHNOLOGIES

SANTA CRUZ, CA U.S.A (831) 2 2 2 - 0717 WWW.ZEBAX.COM

SPECIFIED DIMENSIONS ARE INCHES (MM). ROHS COMPLIANT

ASSEMBLY DRAWING

ITEM: ZX122S1APS

DESCRIPTION:

PCISIG M.2 NGFF Socket 1 Key A passive breakout adapter power measurement module

CHECKED: M. MARINA

MATTHEW CT

REVISSION: 1.0

F

Е

D

C

В

SHEET: 3 OF 3